

Mini keyboard receiver synchronization


1. Take out the dongle from the side of mini keyboard.






2. Connect the dongle to a USB port in Xtreamer Ultra



3. Turn on the power of full charged mini-keyboard.



4. To pair the keyboard press Fn + RF buttons simultaneously. When the devices are paired LED indicator will blink.



5. At this time, Press the button of receiver by a pen to try Sync connection.



6. Check the connection status by keyboard button.

7. If connection is failed, go back to No.2 above and start over.

8. Check the connection status after turn the power off and on again of mini keyboard.